


# FENWAL SENSOR AE90-FEN

## Description

Thermal-thermostatic detectors for special installations, such as tanks and liquid tanks.  
There are several models calibrated at different temperatures (from 60°C to 310°C), both open and closed circuit.



## Connection scheme



## MODELS

T <sup>a</sup>	SIMPLE THREAD BRASS	T <sup>a</sup>	DOUBLE THREAD STAINLESS STEEL
61°	AE90/FEN61	61°	AE90/FEN61D
71°	AE90/FEN71	71°	AE90/FEN71D
88°	AE90/FEN88	88°	AE90/FEN88D
99°	AE90/FEN99	99°	AE90/FEN99D
107°	AE90/FEN107	107°	AE90/FEN107D
135°	AE90/FEN135	135°	AE90/FEN135D
163°	AE90/FEN163	163°	AE90/FEN163D
182°	AE90/FEN182	182°	AE90/FEN182D
232°	AE90/FEN232	232°	AE90/FEN232D
260°	AE90/FEN260	260°	AE90/FEN260D
315°	AE90/FEN315	315°	AE90/FEN315D
385°	AE90/FEN385	385°	AE90/FEN385D